

Gateway for integration of BACnet IP devices into Modbus (RTU and TCP) systems.

# Integrate Daikin VRV Air Conditioners into your Modbus

system (SCADA, BMS, PLC...). For this, Daikin VRV system must be equipped with Daikin BACnet gateway DMS502B51.



#### The BACnet side of IntesisBox

IntesisBox is a BACnet IP client device allowing to read/write points of other BACnet IP device(s) connected to a BACnet network, and offering these point's values through its Modbus interface. BACnet interface of IntesisBox supports reading of other BACnet devices by continuous polling or by subscription requests (COV). All the updated readings are maintained in IntesisBox memory ready to be served to Modbus when requested.

#### The Modbus side of IntesisBox

After the start up process, IntesisBox listen for any read or write request received from Modbus system. If it is read request, IntesisBox serves the updated point's values in its memory. If it is a write request, performs the writing of the remote BACnet device's point associated immediately. Modbus interface of IntesisBox supports Modbus TCP or Modbus RTU (RS232 or RS485), software configurable, and acts as a Modbus slave device.

#### The configuration of IntesisBox

IntesisBox Modbus Server series are configured using LinkBoxMB, a software tool for windows<sup>™</sup> which is supplied along with the purchase of IntesisBox with no additional cost. With the standard installation of LinkBoxMB, a Demo project for integration of BACnet devices is also installed, using this demo project makes the engineering needed for this integration easy and quick, almost plug&play.





## IntesisBox capacity

| Element                     | Max.<br>(Basic<br>version) | Max.<br>(Extended<br>version) | Notes   |
|-----------------------------|----------------------------|-------------------------------|---|
| Type of BACnet devices      |                            |                               | Only those supporting <i>BACnet ASHRAE 135</i><br>– 2001 Annex J - BACnet/IP protocol,<br>commonly referred as BACnet/IP. |
| BACnet points supported     | 500                        | 3000                          | Maximum number of points that can be defined into IntesisBox.   |
| BACnet IP devices supported | 1                          | 16                            | Maximum number of different BACnet IP devices that can be defined into IntesisBox (to read/write points into them).       |

There are two different versions of *IntesisBox<sup>®</sup> Modbus Server - BACnet/IP Client* with different capacity every one of them.

- Basic version with capacity of 500 points and 1 BACnet/IP device. Ref.: IBOX-MBS-BAC-A.
- Extended version with capacity of 3000 points and 16 BACnet/IP devices. Ref.: IBOX-MBS-BAC-B.





## Sample applications

Integration of any BACnet/IP device into Modbus control systems.







## **Typical application**

Integration of Daikin VRV Air Conditioners into a Modbus enabled control system (BMS, PLC, SCADA, Controller...).

For this application, Daikin VRV Air Conditioning system must be equipped with Daikin BACnet gateway (model DMS502B51), this Daikin gateway is normally commissioned by Daikin technical personnel, contact your nearest Daikin distributor for details.

In the technical documentation of IntesisBox supplied with the device, extended details on how to configure IntesisBox for this application is provided.

Intesis Software provides sample projects for IntesisBox with specific configuration to integrate Daikin VRV system, with these sample projects the configuration and commissioning of IntesisBox for this application becomes easy and quick, almost plug & play.







## Modbus interface of IntesisBox

#### **Functions supported**

- Modbus functions 03 and 04 (*read holding registers* and *read input registers*) can be used to read Modbus registers.
- Modbus functions 06 and 16 (*Single Multiple Holding Registers* and *Write Multiple Holding Registers*) can be used to write Modbus registers.
- If *poll records* are used to read or write more than one register, it is necessary that the range of addresses requested contains valid addresses, if not the corresponding Modbus error code will be returned.
- Modbus error codes are fully supported, they will be sent whenever a non valid Modbus action or address is required.

#### Data Formats

The Modbus registers can be of 2 bytes (16 bits) or of 4 bytes (32 bits).

- For 2 bytes (16 bits) registers, its content is expressed always in MSB..LSB.
- For 4 bytes (32 bits) registers, its content (the way IntesisBox handles the byte order) can be one of 3 different options, configurable, this has been implemented to avoid problems reading 32 bits registers, because Modbus master systems handle differently byte order of 32 bits registers depending on manufacturer/device.

| Modbus data coding | • | 16 bits unsigned    |
|--------------------|---|---------------------|
| formats supported  | • | 16 bits signed      |
|                    | • | 16 bits signed * 10 |
|                    | • | 32 bits unsigned    |
|                    | • | 32 bits signed      |
|                    | • | 32 bits float       |

#### Modbus RTU

- Baud rate can be selected from 1200, 2400, 4800, 9600, 19200, 38400 and 56700. (Data Bits: 8, parity: none, Stop Bits: 1).
- Modbus slave number can be configured. Physical connection (RS232 or RS485) can also be selected.
- Only the lines RX, TX and GND of the RS232 connector are used (TX/RX+ and TX/RX- for RS485).

#### Modbus TCP

- The TCP port to use can be configured (by default 502 is used).
- The IP address, subnet mask and default router address to use by IntesisBox can be also configured.

#### Address Map

The Modbus address map is fully configurable, any point in the IntesisBox can be freely configured with the desired Modbus register address.





## **BACnet IP interface of IntesisBox**

| BACnet interface                    |   |  |  |
|-------------------------------------|---|--|--|
| Device type                         | Client  |  |  |
| BACnet modes<br>supported           | BACnet/IP   |  |  |
| Configuration parameters per        | <ul><li>IP address.</li><li>BACnet port.</li></ul>  |  |  |
| BACnet device<br>defined            | <ul> <li>BACnet device number (device instance number).</li> <li>Name.</li> </ul>   |  |  |
| Interactivity with<br>BACnet system | <ul> <li>Point's Read/Write allowed.</li> <li>Reading of BACnet points by Polling or Subscription requests (COV).</li> <li>See BACnet interface specifications below for more details.</li> </ul> |  |  |

#### **Specifications**

BACnet Conformance Class Supported: Class 3

BACnet Standard Application Services Supported:

|                            | Initiate<br>Requests | Executes<br>Requests |
|----------------------------|----------------------|----------------------|
| ConfirmedCOVNotification   |                      | X                    |
| Subscribe COV              | Х                    |                      |
| UnconfirmedCOVNotification |                      | Х                    |
| ReadProperty               | Х                    |                      |
| WriteProperty              | Х                    |                      |
| Who-Is                     | Х                    |                      |
| I Am                       |                      | Х                    |

Data Link Layer Option: BACnet IP, (Annex J)

No Segmented Requests/Responses Supported

#### BACnet Standard Object Types Supported

| Object Type       | Property      | Description                                      |
|-------------------|---------------|--|
| Analog Input      | Present Value | Analog signal. i.e. Ambient temperature.         |
| Analog Output     | Present Value | Analog signal.                                   |
| Analog Value      | Present Value | Analog signal. i.e. Temperature set point value. |
| Binary Input      | Present Value | Digital signal. i.e. ON/OFF status.              |
| Binary Output     | Present Value | Digital signal. i.e. ON/OFF command.             |
| Binary Value      | Present Value | Digital signal. i.e. ON/OFF status/command.      |
| Multistate Input  | Present Value | Multistate signal. i.e. Working mode status.     |
| Multistate Output | Present Value | Multistate signal.                               |
| Multistate Value  | Present Value | Multistate signal. i.e. Working mode command.    |





## **Configuration tool**

| LinkBoxMB | <ul> <li>Visual engineering tool, easy of use, for gateway's configuration and<br/>supervision compatible with Microsoft Windows operating systems, supplied<br/>with the gateway free of charge.</li> </ul>   |
|-----------|--|
|           | <ul> <li>Multi-window tool allowing to supervise simultaneously the communication<br/>activity with both protocols (systems), real time values for all the signals<br/>allowing to modify any value (very useful for test purposes), console window<br/>showing debug and working status messages, and configuration windows to<br/>configure all the gateway's parameters and signals.</li> </ul> |
|           | <ul> <li>Signals configuration in plain text files (tab separated) for easy and quick<br/>configuration using Microsoft Excel (very useful in projects with a lot of points).</li> </ul>   |
|           | <ul> <li>Allows configuring the gateway's parameters and signals while in off-line (not<br/>connected to the gateway).</li> </ul>  |
|           | <ul> <li>Connection to the gateway for download the configuration and supervision by<br/>using serial COM port of the PC (serial cable supplied with the gateway).</li> </ul>  |
|           | <ul> <li>Allows configuring all the external protocols available for IntesisBox<sup>®</sup> Modbus<br/>Server series.</li> </ul>   |
|           | <ul> <li>Upgrades for this software tool available free of charge whenever a new<br/>protocol is added to the IntesisBox<sup>®</sup> Modbus Server series.</li> </ul>  |
|           | <ul> <li>Multi-project tool allowing having in the engineer's PC the configuration for all<br/>the sites with different IntesisBox<sup>®</sup> Modbus Server series gateways.</li> </ul>   |
|           | <ul> <li>Multi-language tool, all the language-dependent strings are in a plain text file<br/>(tab separated) for easy modification or addition of new languages.</li> </ul>   |
|           | <ul> <li>A list of system commands is available to send to the gateway for debugging<br/>and adjust purposes (Reset, Date/time consultation/adjust, Firmware version<br/>request).</li> </ul>  |

|     | IDay     |                      | Deserve               | Termut  | Objections      | I Farmah I            | D-S-ID AV | الفرمة برو |
|-----|----------|----------------------|-----------------------|---------|-----------------|-----------------------|-----------|------------|
| 1   | Uev<br>1 | 999 Communication Er | Property              | Signal  | Ubject instance | 1 16 bits unsigned    | Point R/W | 1 Yes      |
|     |          | 0-Analog Input       | -<br>85-Present Value | Test Al |                 | 3.16 bits signed * 10 | 2 0.8     | 1.Yes      |
| - 2 | i i      | 1-Analog Output      | 85-Present Value      |         | 1               | 7-32 hits float       | 3 2-BW    | 1-Yes      |
| 0   | 1        | 2-Analog Value       | 85-Present Value      | Test AV | 1               | 7-32 bits float       | 5 2-RW    | 1-Yes      |
| Ę   | 1        | 3-Binary Input       | 85-Present Value      | Test Bl | 1               | 1-16 bits unsigned    | 7 0-R     | 1-Yes      |
| E   | 1        | 4-Binary Output      | 85-Present Value      | Test BO | 1               | 1-16 bits unsigned    | 8 2-RW    | 1-Yes      |
| 7   | 1        | 5-Binary Value       | 85-Present Value      | Test BV | 1               | 1-16 bits unsigned    | 9 2-RW    | 1-Yes      |
| 8   | 1        | 13-Multistate Input  | 85-Present Value      | Test MI | 1               | 1-16 bits unsigned    | 10 0-R    | 1-Yes      |
| 9   | 1        | 14-Multistate Output | 85-Present Value      | Test MO | 1               | 1-16 bits unsigned    | 11 2-RW   | 1-Yes      |
| 10  | 1        | 19-Multistate Value  | 85-Present Value      | Test MV | 1               | 1-16 bits unsigned    | 12 O-R    | 1-Yes      |





### **Mechanical & Electrical characteristics**



| Enclosure            | Plastic, type PC (UL 94 V-0). Dimensions: 107mm x 105mm x 58mm. |
|----------------------|---|
| Colour               | Light Grey. RAL 7035.   |
| Power                | 9 to 30Vdc +/-10% 1.4W.   |
|                      | 24Vac +/-10% 1.4VA.   |
|                      | Plug-in terminal bloc for power connection (2 poles).           |
| Mounting             | Surface.  |
|                      | Wall.   |
|                      | DIN rail EN60715 TH35.  |
| Modbus RTU ports     | 1 x Serial RS232 (DB9 male DTE).                                |
|                      | 1 x Serial RS485 (Plug-in screw terminal block 2 poles).        |
| Modbus TCP &         | 1 x Ethernet 10BT RJ45.   |
| BACnet IP port       |   |
| LED indicators       | 1 x Power.  |
|                      | 2 x Serial port (Modbus RTU) activity (Tx, Rx).                 |
|                      | 2 x Ethernet port link and activity (LNK, ACT).                 |
| Console port         | RS232. DB9 female connector (DCE).                              |
| Configuration        | Via console port. <sup>1</sup>                                  |
| Firmware             | Allows upgrades via console port.                               |
| Operational          | -40 °C to +70 °C  |
| temperature          |   |
| Operational humidity | 5% to 95%, non condensing                                       |
| Protection           | IP20 (IEC60529).  |
| RoHS conformity      | Compliant with RoHS directive (2002/95/CE).                     |
| Certifications       | CE  |

<sup>1</sup> Standard cable DB9male-DB9female 1,8 meters long is supplied with the device for connection to a PC COM port for configuring and monitoring the device. The configuration software, compatible with Windows<sup>®</sup> operating systems, is also supplied.





## IntesisBox<sup>®</sup> Modbus Server - BACnet/IP Client datasheet v10 r11eng



Recommended available space for its installation into a cabinet (wall or DIN rail mounting), with space enough for external connections



АРКТИКА

